

sanitas

MANIKÜRE-/PEDIKÜRE-SET | MANICURE/PEDICURE SET

SMA 35



Rechts-/
Linkslauf



2 Geschwindig-
keitsstufen



Für gepflegte Hände und Füße

7 hochwertige Aufsätze aus Saphir und Filz:

1. Saphirkegel: Entfernen von trockener Haut, Hornhaut oder Schwielen an Fußsohle und Ferse und Bearbeiten der Nägel
2. Saphirscheibe, fein: Feilen und Bearbeiten der Nägel, feine Körnung
3. Saphirscheibe, grob: Feilen und Bearbeiten der Nägel, grobe Körnung
4. Saphir-Hornhautschleifer: Schnelles Entfernen dicker Hornhaut oder großer Schwielen an Fußsohle oder Ferse
5. Flammenfräser: Zum Lösen eingewachsener Nägel
6. Zylinderfräser: Abschleifen und grobes Glätten verholzter Fußnageloberflächen
7. Filzkegel: Glätten und Polieren des Nagelrands nach dem Feilen sowie zur Säuberung der Nageloberfläche

Drehzahl: 3.800/4.600 U/min. \pm 14%

2 Geschwindigkeitsstufen, Rechts- und Linkslauf

Inklusive Aufbewahrungstasche

Netzbetrieb:

Eingang: 100-240 V ~ 50/60 Hz; 0,5 A

Ausgang: 30,0 V; 0,25 A; 7,5 W

Produktmaße: 15 x 4 x 4 cm

Produktgewicht: ca. 104 g

2 Jahre Garantie

VE: 3 / Transportkarton: 6 x 3

EAN-Nr.: 4211125 57105 4

Art.-Nr.: 571.05

For well-cared hands and feet

7 high-quality sapphire and felt attachments:

1. Sapphire cone: removing dry skin and softening calluses on the sole and heel
2. Fine-Grain Sapphire Wheel: filing nails to reduce length
3. Coarse-Grain Sapphire Wheel: filing thicker nails to reduce length
4. Sapphire callus rasp: fast removal of thick or large calluses on the sole and heel
5. Flame-Shape Cutter: removing ingrowing nails
6. Cylindrical Cutter: smoothing rough and ridged toenail surfaces
7. Felt Cone: smoothing and buffing nail tips after filing and for cleaning the surface of the nails

Speed: 3,800/4,600 U/min. \pm 14%

2 speed settings, Clockwise and anticlockwise rotation

Storage bag included

Mains operation:

Input: 100-240 V ~ 50/60 Hz; 0.5 A

Output: 30.0 V; 0.25 A; 7.5 W

Product measurements: 15 x 4 x 4 cm

Product weight: approx. 104 g

2 year guarantee

Sales unit: 3 / Shipping carton: 6 x 3

EAN no.: 4211125 57105 4

Item no.: 571.05